

BAXTER RX

COMFORT AND INGENUITY

BAXTER RX, the alternative to the TWISTER model, offers total comfort thanks to its highly wrap-around frame. With its waterproof foam and ingenious system for attaching the strap, BAXTER RX offers effective protection from sprays of solids and liquids, and from dust.

Trivex and Polycarbonate lenses available.




49 g

SUPPLIED WITH

Hard case,
microfibre cloth,
cord



FRAME

• TR90

SUPPLIED WITH

Foam and strap



LENS MATERIAL AVAILABLE

• Trivex
• Polycarbonate



Ref. BAXN

+ INCREASED PROTECTION



+ WRAP-AROUND FRAME

+ WATERPROOF FOAM AND REMOVABLE STRAP

bollé
SAFETY

BAXTER RX



COMFORT AND INGENUITY

MODEL	VERSIONS	REF.	SIZE	LENS HEIGHT	LENS MARKING	TEMPLE LENGTH
BAXTER RX	Worn as spectacles Worn as strap + foam	BAXN	66/17	36 mm	 RIO (for clear outdoor)  RI (for tinted outdoor)	130 mm

LENS MARKING

- R.** The letter 'R' signifies prescription eye protectors.
- I.** The letter 'I' signifies 'Medium Impact' approval.
- O.** The letter 'O' marking signifies that the product has been approved for the use both outdoors and indoors and the terminology used by Australian standards is 'outdoor untinted'. This marking appears on all clear, amber and contrast lenses.

OCULAR LENS CATEGORY:

-  RIO for clear outdoor
-  RI for tinted outdoor

FRAME MARKING

AS/NZS 1337: tested and approved to Australian Standards – Prescription Eye Protectors against Low and Medium Impact.

CLEANING AND STORAGE

CLEANING : The lenses should be cleaned regularly. Bollé Safety recommends only using the B-clean lens cleaning system.

MAINTENANCE : Pitted, scratched or damaged lenses must be replaced by replacing the complete product. If the frame is damaged, also replace the complete product. After each use it is recommended to keep the spectacles in a rigid case.

STORAGE : All products must be stored in a dry and clean environment.

STANDARD ASSEMBLY RESTRICTIONS:

Maximum sphere power: +3.00/-2.00

Maximum cylinder compared with sphere: -2.00

CORRECTED BASE:

Corrected base: 8

CHARACTERISTICS

LENSES	PC - 2,2 mm - Curve 8
FRAME	TR90
TEMPLES	TR90
STRAP	Nylon
FOAM	PC + EVA

20/04/2019

Bollé Safety APAC
Bollé Safety AU Pty Limited
32-40 Fairchild Street
Heatherton VIC 3202
T: 1300 138 098
E: rxsafetyau@bolle-safety.com

bollesafety.com.au

New Zealand
T.: 0800 2655 369
E: rxsafetyau@bolle-safety.com

bolle
SAFETY