

B808

STYLISH & UNIVERSAL

Bollé Safety offers a simple and flexible system, based on unique pricing. The Rx range is composed of a wide range of frames that can be glazed with 4 types of prescription lenses (single vision, bifocal, progressive and extended near) and 2 different lens materials (polycarbonate or trivex).



Non-slip temples



Non-slip bridge



Size S: 27g | Size L: 29g

SUPPLIED WITH

Hard case,
microfibre cloth,
cord



FRAME

• PC

LENS MATERIAL AVAILABLE

• Trivex
• Polycarbonate

Size S



Ref. B808BS



Ref. B808RS

Size L



Ref. B808BL



Ref. B808RL

+ VENTILATED SIDE SHIELDS

+ 2 SIZES - 2 COLOURS

+ PC FRAME





+ COMFORTABLE, NON-SLIP TIPGRIP TEMPLES

+ NON SLIP NOSE BRIDGE

bollé
SAFETY

B808



STYLISH & UNIVERSAL

MODEL	VERSIONS	REF.	SIZE	LENS HEIGHT	LENS MARKING	TEMPLE LENGTH
B808 	Small - S	B808RS	52/18	33 mm	 RI0 (for clear outdoor)  RI (for tinted outdoor)	133 mm
	Large - L	B808RL	54/18	34 mm		139 mm
B808  Gunmetal	Small - S	B808BS	52/18	33 mm		133 mm
	Large - L	B808BL	54/18	34 mm		139 mm

LENS MARKING

- R.** The letter 'R' signifies prescription eye protectors.
- I.** The letter 'I' signifies 'Medium Impact' approval.
- O.** The letter 'O' marking signifies that the product has been approved for the use both outdoors and indoors and the terminology used by Australian standards is 'outdoor untinted'. This marking appears on all clear, amber and contrast lenses.

OCULAR LENS CATEGORY:

-  **RI0** for clear outdoor
-  **RI** for tinted outdoor

STANDARD ASSEMBLY RESTRICTIONS:

Maximum sphere power: +5.00/-6.00

Maximum cylinder compared with sphere: -3.00

CORRECTED BASE:

Corrected base: 6 (size S) / 6 (size L)

FRAME MARKING

AS/NZS 1337: tested and approved to Australian Standards – Prescription Eye Protectors against Low and Medium Impact.

CLEANING AND STORAGE

CLEANING : The lenses should be cleaned regularly. Bollé Safety recommends only using the B-clean lens cleaning system.

MAINTENANCE : Pitted, scratched or damaged lenses must be replaced by replacing the complete product. If the frame is damaged, also replace the complete product. After each use it is recommended to keep the spectacles in a rigid case.

STORAGE : All products must be stored in a dry and clean environment.

CHARACTERISTICS	
LENS	Trivex, Polycarbonate
TYPES OF CORRECTIONS AVAILABLE	Single vision, Bifocal, Progressive, Extended near, Transitions, Polarised, AR coating, Blue shield
FRAME	PC / Gunmetal or Red
STRAP	Non applicable
FOAM	Non applicable

20/04/2019

Bollé Safety APAC
Bollé Safety AU Pty Limited
32-40 Fairchild Street
Heatherton VIC 3202
T: 1300 138 098
E: rxsafetyau@bolle-safety.com

bollesafety.com.au

New Zealand
T.: 0800 2655 369
E: rxsafetyau@bolle-safety.com

bolle
SAFETY